

# **BWT** bestsave

# PERFECT BASIC LIMESCALE PROTECTION FOR AUTOMATIC COFFEE MACHINES

The new BWT bestsave limescale protection pad offers the perfect basic limescale protection for all hot drinks machines with integrated water tanks. This means that BWT bestsave, in all its various sizes, is compatible with almost every type of coffee-maker, automatic coffee machine and compact vending equipment.

Whether supplied to caterers, bakers, small cafés or to offices in the Office Coffee sector, BWT bestsave is still the easiest and most efficient solution for top quality drinks.

### BENEFITS OF BWT BESTSAVE AT A GLANCE:

- Usable in all compact coffee and vending machines with built-in water tanks
- Easy to use and reliable
- The very best quality drinks, consistently, every time
- Safe and effective protection against limescale
- Less maintenance and descaling required

### **BWT BESTSAVE TECHNOLOGY**

- Simplicity: no installation needed in the water tank
- All materials used are of food-grade quality
- Hygienic protection against bacterial growth
- Removal of unwanted tastes and smells (e.g. chlorine)



# HOW DOES THE BWT LIMESCALE PROTECTION PAD WORK?

A food-safe ion exchanger binds calcium ions in the water, preventing the build-up of calcium carbonate that can lead to those all too familiar calcium deposits.

For optimum flow BWT's fleece is made from hygienic, food-grade quality material.

**Benefit:** Preserves expensive high-tech equipment. The preparation stage works reliably, without disruption, at the required temperature and for the correct quantity of drinks, while the integrated activated carbon binds all unwanted elements in the water.

**Benefit:** Improved water taste and smell mean perfect drinks every time. And any heavy metal content, such as copper and zinc, which can originate from the water pipes, is also significantly reduced. Everything is wrapped securely in food-safe fleece material, guaranteeing optimum flow through the filter.






#### **OPERATION AND USE**

The BWT bestsave limescale protection pad is very easy to use. As soon as you have unpacked it, give it a quick rinse under the tap and place it directly on the bottom of the water tank in your coffee machine. With the tank full, the ion exchanger takes 8–10 hours to remove the calcium from the untreated water. For best results carry out the optimisation over night so that there is sufficient water available for coffee the following day. BWT bestsave pads therefore offer basic, reliable limescale protection for coffee makers, vending and automatic coffee machines.


Change the bestsave limescale protection pad as soon as the maximum number of units (number of tank refills) have been reached. You can work out the potential number of refills quite easily by using the table below. Just match your local limescale content (water hardness) with the size of the water tank used and read off the number of refills – job done.

In the interest of hygiene, the bestsave limescale protection pad should not be left in the tank for longer than two months, at which point it should be exchanged for a new one. Simply dispose of your used BWT bestsave limescale protection pads in the waste.



# DIMENSIONS OF THE BWT BESTSAVE LIMESCALE PROTECTION PAD:

| BWT bestsave   | s  | М   | L   |  |
|----------------|----|-----|-----|--|
| Width A in mm  | 95 | 126 | 150 |  |
| Depth B in mm  | 65 | 82  | 82  |  |
| Height C in mm | 17 | 20  | 24  |  |



### **CAPACITIES**

| Туре   | BWT bestsave S  |       | BWT bestsave M |            |            | BWT bestsave L |            |       |       |
|--|---|-------|----------------|------------|------------|----------------|------------|-------|-------|
| Filter capacity<br>at 10 °dKH <sup>(1)</sup> → | 50 litres   |       | 100 litres     |            | 200 litres |                |            |       |       |
| Temporary                                      | Tank capacity / tank refills per day and temporary hardness |       |                |            |            |                |            |       |       |
| hardness <sup>(1)</sup> ↓                      | 0.75 L  | 1.0 L | 1.5 L          | 1.0 L      | 2.0 L      | 3.5 L          | 2.0 L      | 3.5 L | 5.0 L |
| 10 °dKH (soft)                                 | 66  | 50    | 33             | 100        | 50         | 29             | 100        | 58    | 40    |
| 15 °dKH (medium)                               | 44  | 33    | 22             | 66         | 33         | 20             | 66         | 40    | 27    |
| 20 °dKH (hard)                                 | 33  | 25    | 16             | 50         | 25         | 15             | 50         | 30    | 20    |
| Order no.                                      | KS08I00A00  |       |                | KS10100A00 |            |                | KS12I00A00 |       |       |

(1) °dKH = German temporary hardness. Subject to change.

# DO YOU ALREADY KNOW ABOUT THE BWT BESTCUP PREMIUM INLINE-FILTER FOR COMPACT FULLY AUTOMATIC COFFEE MACHINES?

Coffee water optimised by BWT bestcup PREMIUM filters ensures optimum enjoyment of coffee and will protect the valuable technology of your machine from damage caused by lime and gypsum deposits. They have a special connection and are simply placed in the intake fittings in the coffee machine tank.

The patented BWT magnesium technology also mineralises the water with the flavour carrier magnesium for the best coffee taste and a perfect crema.



## MANUFACTURER:

BWT water + more GmbH Walter-Simmer-Str. 4 A-5310 Mondsee



BWT Denmark: salg@bwt.dk · Tel.: +45 43 600 500

BWT Sweden: info@bwtwater.se · Tel.: +46 40691 4500

BWT Norway: firmapost@bwtwater.no · Tel.: +47 6717 7000

BWT Finland: info@bwtwater.fi · Tel.: +358 (0)2-436 7300

